

REMOTE BYPASS SWITCH INSTRUCTIONS

1. Determine where the switch box is to be located (maximum of 4 ft from EMS).
2. Feed cable into input end of EMS.
3. Attach black conductor to blank male terminal located on input side under the white power cord neutral.
4. Remove blue jumper wire that is attached to relay on one end and the other is not connected to anything. Replace blue jumper with red switch wire.
5. Replace EMS cover and apply power to EMS.
6. Next, be sure switch is mounted properly according to printing on box, if not, remove switch, NOT box and orientate so that switch is matched up to box printing.
(If there is no delay when power is Applied, the EMS is in bypass)
7. Installation is complete. If you have any questions, Please call: **(919) 267-6948**

REMOTE BYPASS SWITCH INSTRUCTIONS

1. Determine where the switch box is to be located (maximum of 4 ft from EMS).
2. Feed cable into input end of EMS.
3. Attach black conductor to blank male terminal located on input side under the white power cord neutral.
4. Remove blue jumper wire that is attached to relay on one end and the other is not connected to anything. Replace blue jumper with red switch wire.
5. Replace EMS cover and apply power to EMS.
6. Next, be sure switch is mounted properly according to printing on box, if not, remove switch, NOT box and orientate so that switch is matched up to box printing.
(If there is no delay when power is Applied, the EMS is in bypass)
7. Installation is complete. If you have any questions, Please call: **(919) 267-6948**

REMOTE BYPASS SWITCH INSTRUCTIONS

1. Determine where the switch box is to be located (maximum of 4 ft from EMS).
2. Feed cable into input end of EMS.
3. Attach black conductor to blank male terminal located on input side under the white power cord neutral.
4. Remove blue jumper wire that is attached to relay on one end and the other is not connected to anything. Replace blue jumper with red switch wire.
5. Replace EMS cover and apply power to EMS.
6. Next, be sure switch is mounted properly according to printing on box, if not, remove switch, NOT box and orientate so that switch is matched up to box printing.
(If there is no delay when power is Applied, the EMS is in bypass)
7. Installation is complete. If you have any questions, Please call: **(919) 267-6948**

REMOTE BYPASS SWITCH INSTRUCTIONS

1. Determine where the switch box is to be located (maximum of 4 ft from EMS).
2. Feed cable into input end of EMS.
3. Attach black conductor to blank male terminal located on input side under the white power cord neutral.
4. Remove blue jumper wire that is attached to relay on one end and the other is not connected to anything. Replace blue jumper with red switch wire.
5. Replace EMS cover and apply power to EMS.
6. Next, be sure switch is mounted properly according to printing on box, if not, remove switch, NOT box and orientate so that switch is matched up to box printing.
(If there is no delay when power is Applied, the EMS is in bypass)
7. Installation is complete. If you have any questions, Please call: **(919) 267-6948**