

RDS Instructions

Includes: digital display, switch box, 3-foot and 14-foot data cables.

Installation

Disconnect existing display from EMS and connect to switch box input.

Connect 3-foot cable to switch box output and existing (mounted) display.

Connect new 14-foot cable to last switch box outlet and route cable to desired location and connect new display.

You can only read one display at a time so when the switch is in one direction the corresponding display will light and switch box LED will light.

Note: only use enclosed data cable, regular phone cable will not work.

RDS Warranty is for three years.

ProgressiveIndustries.net

RDS Instructions

Includes: digital display, switch box, 3-foot and 14-foot data cables.

Installation

Disconnect existing display from EMS and connect to switch box input.

Connect 3-foot cable to switch box output and existing (mounted) display.

Connect new 14-foot cable to last switch box outlet and route cable to desired location and connect new display.

You can only read one display at a time so when the switch is in one direction the corresponding display will light and switch box LED will light.

Note: only use enclosed data cable, regular phone cable will not work.

RDS Warranty is for three years.

ProgressiveIndustries.net

RDS Instructions

Includes: digital display, switch box, 3-foot and 14-foot data cables.

Installation

Disconnect existing display from EMS and connect to switch box input.

Connect 3-foot cable to switch box output and existing (mounted) display.

Connect new 14-foot cable to last switch box outlet and route cable to desired location and connect new display.

You can only read one display at a time so when the switch is in one direction the corresponding display will light and switch box LED will light.

Note: only use enclosed data cable, regular phone cable will not work.

RDS Warranty is for three years.

ProgressiveIndustries.net

RDS Instructions

Includes: digital display, switch box, 3-foot and 14-foot data cables.

Installation

Disconnect existing display from EMS and connect to switch box input.

Connect 3-foot cable to switch box output and existing (mounted) display.

Connect new 14-foot cable to last switch box outlet and route cable to desired location and connect new display.

You can only read one display at a time so when the switch is in one direction the corresponding display will light and switch box LED will light.

Note: only use enclosed data cable, regular phone cable will not work.

RDS Warranty is for three years.

ProgressiveIndustries.net